


## Opening PC Case

To Access PC Case, remove 2x security screws at either side of case.



**WARNING**  
Only remove PC Case screws as shown:

## Installing PC

### PC Installation

Position PC with velcro pads (Supplied)

Aline PC with bracket edge

### Monitor Cables

Can be passed through hole provided in worktop after removing grommet

